



Rotary Switch Setting

Position	MIN	50%	MAX
RV1 Operation Intervals (Minutes)	10	35	60
RV2 Operation time (Seconds)	3	6	10

DIP Switch Settings

SW1	1	2	3	4
ON	3-Wire Float	Not In Use	Not In Use	DEMO MODE
OFF	2-Wire Float	Not In Use	Not In Use	Standard Mode



Shabbat Smart Ltd.
 85 Kenilworth Road
 London HA8 8XA
 United Kingdom
 Tel: +44 20 8004 9558
 email: info@ShabbatSmart.com
 www.ShabbatSmart.com

Name: ShabbatSmart Waste Water Pump Controller
Description: Wiring Diagram
Version: 1.1

Scale: NTS
Page: A4
Date: 23/09/2021